Connect your Chromebook to Wi-Fi

To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Turn on Wi-Fi

1. At the bottom right, select the time.
2. Select Not Connected ▼.
   Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi.
3. Turn on **Wi-Fi**.
4. Your Chromebook will automatically look for available networks and show them to you in a list.

If you require further assistance, please contact your Internet provider directly.